

Classification:

BT11-022

Reference:

ITB11-035

Date:

June 13, 2011

G37 CONVERTIBLE; RATTLE OR RUBBING NOISE FROM ROOF AREA

APPLIED VEHICLE: 2009 - 2011 G37 Convertible (HV36)

IF YOU CONFIRM:

There is a rattle or rubbing / creaking noise coming from the roof area (where shown in Figure 1) while driving.

ACTION:

 If a rattling noise is coming from the area(s) shown in Figure 1 (●), perform **Procedure 'A'** starting on Page 3: Replace both center roof panel pin O-rings, and then realign both center panel retainers.


 If a rubbing / creaking noise is coming from the area(s) shown in Figure 1 (↗), perform **Procedure 'B'** starting on Page 5: Clean and condition all roof seal contact surfaces.


Figure 1

IMPORTANT: The purpose of **ACTION** (above) is to give you a quick idea of the work you will be performing. You **MUST** closely follow entirely each **SERVICE PROCEDURE** (as it applies) as it contains information that is essential to successfully completing this repair.

Infiniti Bulletins are intended for use by qualified technicians, not 'do-it-yourselfers'. Qualified technicians are properly trained individuals who have the equipment, tools, safety instruction, and know-how to do a job properly and safely. NOTE: If you believe that a described condition may apply to a particular vehicle, DO NOT assume that it does. See your Infiniti dealer to determine if this applies to your vehicle.

PARTS INFORMATION

DESCRIPTION	PART #	QUANTITY
O-RING	970D3-JJ50A	2
DuPont Krytox® Lubricant – GPL-105 (1)	82306-5Z000	(2)

- (1) Order this product from your PDC.
- (2) One container per vehicle.

CLAIMS INFORMATION

Submit a Primary Failed Part (PP) line claim using the following claims coding:

DESCRIPTION	PFP	OP-CODE	SYM	DIAG	FRT
Perform Ball Joint and Socket Align Adjustment	73159-JJ50B	SX06AA	ZL	46	0.3

And if needed

DESCRIPTION	PFP	OP-CODE	SYM	DIAG	FRT
Clean All Weather Strips	97170-JJ50A	SX07AA	ZL	46	0.3




TP110364

Lubricant

SERVICE PROCEDURE

Procedure A – Repair Rattle Noise


1. Partly open the retractable hard top as shown in Figure 2.



TP110308


Center roof panel Figure 2

2. Check both O-rings for impressions.
 - If impressions are found on either O-ring, replace both O-rings with a suitable tool (see Figure 2 & 3).
 - There is one (1) O-ring at each rear corner of the center roof panel, mounted on center roof panel pins.



TP110310

Figure 3



TP110309

Figure 4

3. Next, loosen the Torx screws for both rear roof panel retainers (see Figure 5).
 - The retainers are located at both front corners of the rear roof panel.
 - Loosen the retainers enough so they move around easily by hand, but not on their own.
 - Torx screw size: T-30




Figure 5

4. Fully close the retractable hard top.
 - This will allow the retainers to align with the pins.
5. Open the retractable hard top, and then tighten the retainer's Torx screws.
 - Torx screws torque: 9.5 N•m (0.97 kg-m, **84 in lb**)
6. Road test, verify repairs.

Procedure B – Repair Rubbing / Creaking Noise

1. Partly open the retractable hard top as shown in Figure 6.



TP110308

Figure 6

2. Using a damp cloth, clean the contact surfaces of all retractable hard top related weather-strips (see Figure 7).



TP110361

Figure 7

- Also clean the area of the seal (where circled in Figure 7 and 8) on both sides of the vehicle.



TP110362

Figure 8

3. Using your finger, apply a thin coat of DuPont Krytox® Lubricant (see **PARTS INFORMATION**) on all cleaned weather-strip contact surfaces.
 - Make sure to apply lubricant on both surfaces of seals with two (2) contact surfaces. See Figure 9 for example.
 - For cleanliness, it is recommended to use latex or similar type gloves.



Figure 9

4. Road test, verify repairs.

