

# CZP G37 Front Brake Upgrade Template

4-20-09

## Instructions

1. Print out template and check scale is 1:1. All units in mm. Hub register hole (66 mm) should measure 2.60".
2. Cut out around blue line including hub register. It is recommended to trace template to a light piece of cardboard for a final template. The template is the profile of the brake caliper
3. Remove front wheel, insert template inside hub register of wheel and spin in circle. Template should not contact any section of the wheel. It is recommended to add at least 2mm to all dimensions to ensure clearance.

